

# product information sheet

Trade Mark	Electrolux
Model	EOF6H46X2 949497039
Energy Efficiency index EEI – Main Oven	81.2
Energy Efficiency Class – Main Oven	A+
Energy consumption with a standard load, conventional mode(kWh/cycle) – Main Oven	0.93
Energy consumption with a standard load, fan-forced mode (kWh/cycle) – Main Oven	0.69
Number of cavities	1
Heat source	Electricity
Volume (l) - Main Oven	72

## Product information according to Commission regulation (EU) No 66/2014

Attribute Name	Position	Symbol	Value	Unit
Model Denomination			EOF6H46X2 949497039	
Type of oven			Built-in oven	
Mass of the appliance		M	30,0	Kg
Number of cavities			1	
Heat source per cavity (electricity or gas)			Electrical	
Volume per cavity	-	V	72	L
Energy consumption (electricity) required to heat a standardised load in a cavity of an electric heated oven during a cycle in conventional mode per cavity (electric final energy)	-	EC <sup>electric cavity</sup>	0.93	kwh/cycle
Energy consumption required to heat a standardised load in a cavity of an electric heated oven during a cycle in fan-forced mode per cavity (electric final energy)	-	EC <sup>electric cavity</sup>	0.69	kwh/cycle
Energy Efficiency Index per cavity	-	EEI <sub>cavity</sub>	81.2	

### EN 60350-1 - Household electric cooking appliances - Part 1: Ranges, ovens, steam ovens and grills - Methods for measuring performance

#### Suggestions for a correct use in order to reduce the environmental impact:

- Make sure that the oven door is closed properly when the oven operates. Do not open the door too often during cooking. Keep the door gasket clean and make sure it is well fixed in its position.
- Use metal cookware to improve energy saving.
- When possible, do not preheat the oven before cooking.
- Keep breaks between baking as short as possible when you prepare a few dishes at one time.
- Other information available on chapter "Energy Efficiency" of User Manual